


Hera Hammers

Spare parts list




D8-42

Diesel pile hammer D8-42


Hera Machinefabriek B.V.
2e Havenstraat 6
1976 CE IJmuiden
The Netherlands

www.hera-hammers.com
www.dieselhammerparts.com




Hera D8-42

No.	Description	Q' ty	Order-no.
—	Diesel pile hammer D8-42	1	66966
1	cylinder lower part complete page 4	1	66967
2	inner damping ring	1	63478
3	impact block complete page 6	1	65590
4	striking weight(piston)complete page 6	1	65591
5	fuel injection device page 8	1	100570
6	lube pump complete page 14	1	113372
7	cylinder upper part complete page 16	1	100580
8	fuel line/breather line complete page 18	1	66977
9	lube line with connecting parts complete page 20	1	111312
10	trip gear complete page 22	1	104694
11	set of connecting parts page 24	1	44004
12	transport protection kit complete page 26	1	64868
13	guide parts for hammer on request	4	
14	guide parts for trip gear on request	4	
15	tool box complete page 28	1	64865




Hera D8-42 Lower cylinder

No.	Description	Q'ty	Order-no.
—	cylinder lower part complete	1	66967
1	rubber ring	1	63471
2	sealing ring 18×22	1	90002
3	plug screw M18×1.5	1	91460
4	cylinder lower part	1	66968
5	cylinder sleeve(on request)	1	
6	cylinder sleeve(on request)	1	
7	cylinder end ring complete (2 pieces)	1	64417
8	ring(2 pieces)	1	63477
9	threaded insert M24	16	95582
*	Reducer (not marked on drawing)	2	22592
10	grease nipple M10×1	4	90791
11	dowel pin Φ40×75	6	95195
12	reducer screw M24×165	6	20174
*	Ring (not marked on drawing)	2	201001
13	plug screw "Diesel" complete	1	17186
14	plug screw "Diesel"	1	47608
15	chain link, exchangeable	1	2253
16	plug screw "oil" complete	1	17188
17	plug screw "oil"	1	47611
18	chain link, exchangeable	1	2253
19	filter elbow	2	64403
20	filter element	2	99896
21	round sealing ring 36×1.5	2	210607
22	screwed joint	2	66552




Hera D8-42 Impact block complete

No.	Description	Q' ty	Order-no.
1	impact block complete	1	65590
2	impact block	1	63864
3	piston ring	5	63469
4	striking weight (piston) complete	1	65591
5	striking weight (piston)	1	63846
6	piston ring	5	63469
7	catch piston ring	1	63470





Hera D8-42 Fuel injection device

No.	Description	Q'ty	Order-no.
—	fuel injection device	1	100570
1	variable-delivery fuel pump	1	41865
2	injection valve complete	1	104675
3	injection valve body 20°	1	100571
4	spring washer	1	64461
5	locking plate	2	64460
6	valve piston	1	63843
7	pressure spring 15.4×32.8×1.6	1	97569
8	adjusting washer	2	97573
9	threaded pipe joint complete	1	97038
10	threaded pipe joint	1	210404
11	round sealing ring17×1.5	2	97258
12	hollow screw	1	210405
13	dowel pin 21×28	2	95633
14	sealing	1	45647
15	pipe bend	1	100573
16	olive	1	90127
17	union nut M18×1.5	1	90128
18	olive	1	204011
19	union nut M16×1.5	1	204012



Hera D8-42 Fuel injection device

No.	Description	Q' ty	Order-no.
—	variable-delivery fuel pump	1	41865
1	sealing ring A18×22	2	90002
2	plug screw M18×1.5	2	93055
3	pressure piece complete	1	62125
4	push cap	1	62124
5.1	adjusting washer 8.2×19.8×0.3	1	97332
5.2	adjusting washer 8.2×19.8×0.5	1	97333
5.3	adjusting washer 8.2×19.8×0.6	1	97334
5.4	adjusting washer 8.2×19.8×0.4	1	97348
6	push rod	1	62126
7	pressure spring 14.5×34×1	1	22046
8	dowel pin 6×40	1	90150
9	screen pin	1	22049
10	pressure spring 5.5×20×1.2	1	22044
11	round sealing ring22×3	1	91296
12	cam	1	22052
13	cam	1	22051
14	spring	1	22245
15	pin	1	22043
16	pump lever	1	41869
17	swivel spring	1	22062
18	round sealing ring35×2.5	1	92996
19	pressure spring 28×67.2×3.5	1	22060
20	spring retaining collar	1	22058
21	conical ring 2 pieces	1	22059
22	guide sleeve	1	43287
23	holder ring	1	43994
24	dowel pin28×80	4	94315
25	sealing ring A20×24	1	92031
26	locking screw M8×50	1	93456
27	protecting cap	2	93236
28	switch shaft	1	43308
29	pump element complete for 14	1	22903
30	round sealing ring42×3	1	95933
31	round sealing ring46.2×2.65	1	91322
32	round sealing ring43.7×2.65	1	91339
33	rope disc complete	1	22040
34	pump body complete	1	43289
35	dowel pin6×28	1	90137
36	dowel pin5×40	1	90155
37	regulation rope	2	17546
38	pump cover complete page 12	1	43291
39	check-non-return valve completepage12	1	43296
40	suction valve complete page 12	1	41863
41	stop valve complete page 12	1	41868




Hera D8-42 Fuel injection device

No.	Description	Q' ty	Order-no.
1	pump cover complete	1	43291
2	ring	1	22050
3	stop	1	22796
4	stop pin	1	43307
5	dowel pin 10×32	1	90231
6	non-return valve complete	1	43296
7	housing	1	43297
8	valve piston	1	43299
9	pressure spring	1	22034
10	ring type nipple	1	43298
11	stop valve complete	1	41868
12	valve piston	1	43138
13	pressure spring	1	43279
14	round sealing ring12×3	1	94316
15	threaded plug	1	22021
16	pressure spring	1	98929
17	round sealing ring8×3	1	91894
18	valve screw	1	43130
19	circlip 20×1	1	95768
20	ball Ø8.731mm	1	98511
21	suction valve complete	1	41863
22	sleeve	1	41861
23	pressure spring 7.3×8×0.7	1	22022
24	washer	2	22023
25	threaded plug	1	41862
26	ball Ø8.731mm	1	98511




No.	Description	Q'ty	Order-no.
—	lube pump complete	1	113372
1	pin	1	22082
2	sleeve	1	22090
3	adaptor(tube to thread)	1	67290
4	pressure spring7.3×29.4×1.2	1	190479
5	plug screw	1	108311
6	pump lever	1	22081
7	pump body	1	108315
8	pressure spring 10×43×2	1	22089
9	ring	1	67283
10	pressure spring22×52×2.8	1	97325
11	washer	1	67282
12	plug screw	1	91976
13	cylinder screw M8×35	4	90937
14	dowel pin 28×80	2	94315
15	protecting cap	1	93236
16	cylinder complete	1	113373
17	round sealing ring24×3	1	205020
18	round sealing ring26×3	1	91357
19	round sealing ring30×3	1	92952
20	piston complete	1	113228
21	piston	1	201003
22	sliding ring with O-ring	1	94658
23	pressure valve complete	2	108317
24	ring type nipple	2	97949
25	hollow screw A6	2	97948
26	sealing ring A12×15.5	4	91417
27	adaptor(tube to thread)	2	108319
28	plug screw	2	104679
29	pressure spring5×36×0.8	2	190005
30	round sealing ring8×2	4	97855
31	ball Φ6	2	90307
32	plug screw	2	108316
33	sealing ring A20×24	1	92031




Hera D8-42 Upper cylinder

No.	Description	Q' ty	Order-no.
—	cylinder upper part complete	1	100580
1	cylinder upper	1	100578
2	ratchet	2	17039
3	dowel pin 13×60	2	90044
4	grease nipple M10×1	3	90791





Hera D8-42 Fuel line/breather line

No.	Description	Q' ty	Order-no.
—	fuel line/breather line complete	1	66977
1	hose 1.6m long	1	100569
2	hose clip 5/8" -1"	4	94299
3	Y-piece	1	99019
4	hose 0.28m long	1	96504
5	hose 0.36m long	1	207025




Hera D8-42 Lube line with connecting parts

No.	Description	Q' ty	Order-no.
—	lube line with connecting	1	111312
1	hose clip 5/8" -1"	1	94299
2	hose	1	66979
3	hose 1.13m long	2	97714
4	hose 2.4m long	1	111313
5	hose 0.23m long	2	41730
6	hose 1.15m long	2	100568
7	T—piece	2	94522
8	hose clip	10	95115
9	clip	4	2932
10	locking screw M8×12	8	93412
11	ring type nipple	4	97949
12	hollow screw	4	97948
13	sealing ring	8	91417




Hera D8-42 Trip gear

No.	Description	Q' ty	Order-no.
—	trip gear complete	1	104694
1	guide body complete	1	104697
2	dowel pin 8×50	1	90380
3	pawl	1	64192
4	joint bole	2	1106
5	dowel pin 10×75	2	91321
6	dowel pin 6×60	2	90160
7	shackle	2	1104
8	leaf spring	1	39382
9	lock screw M10×30	4	93414
10	torsion spring	1	39381
11	pin complete	1	104954
12	split pin 8×80	1	90637
13	lever	1	64189
14	pin	1	64190
15	circlip 30×1.2	1	90221
16	driving pin	1	108300
17	cam with lever complete	1	104695
18	cover	1	104698
19	grease nipple M10×1	2	90791



Hera D8-42 Connecting parts

No.	Description	Q' ty	Order-no.
—	set connecting parts for cylinder upper part with cylinder lower part:	1	44004
1	reduced screw M24 for variable-delivery fuel pump with cylinder lower part:	4	20174
2	stud bolt M16	6	20189
3	locking nut M16 for lube pump with cylinder lower part:	6	94722
2	stud bolt M16	2	20189
3	locking nut M16 for injection vale with cylinder lower part:	2	94722
4	hexagon screw M16×45	4	95639



Hera D8-42 Transport protection complete

No.	Description	Q' ty	Order-no.
—	transport protecting complete		64868
1	locking screw M42×3	1	16890
2	hexagon screw M24	2	22702
3	impact block securing clamp	1	64869
4	protecting cap	1	64875
5	exhaust cover complete	1	64498
6	screw complete	1	20076
7	dowel pin 5×50	1	90661
8	dowel pin 3×20	1	91444
9	pressure spring	1	20082
10	cover	1	64500

No.	Description	Q' ty	Order-no.
—	tool box complete	1	64865
1	tool book	1	90890
2	piston ring fitting band complete	1	102140
3	piston ring fitting pliers complete	1	626
4	punch $\Phi 12/\Phi 16$	1	93349
5	punch $\Phi 4/\Phi 8$	1	90354
6	ratchet spanner	1	90196
7	ring screw M30	1	91336
8	double ended open spanner 30×32	1	90655
9	double ended open spanner 19×22	1	90443
10	double ended ring spanner 17×19	1	92015
11	double ended ring spanner 22×24	1	95834
12	single ended open spanner 27	1	90465
13	single ended open spanner 46	1	90184
14	spanner 15"	1	93352
15	socket wrench SW36	1	94461
16	angled screw driver 5	1	90055
17	angled screw driver 6	1	90862
18	angled screw driver 8	1	90657
19	pliers A19	1	90785
20	Grease gun	1	90795
21	0.5kg Molyube grease	1	93551